

INSTALLING THE FLOOR

<UfYei]b'Xc' bchfYVta a YbX'fUd]b['h.Y'ffid'fUd]b[ficZ<UfYei]b'<]!G\]bY'Ug'h]g'k]''cc_'
i bgj[\hmiUbX'fYa cj U'cZ'h.Y'fUdY' a UmXUa U[Y'h.Y'gi fZUW'cZ'h.Y'Zccf''<]!G\]bY'g\ci 'X'
U'k Uhg'VY']bgtU'YX'VmiUd]b['h.Y'i bXYfgjXY'cZ'h.Y'Zccf''

D'YUgY' bchY' h.Uh'U'ei U']m]bgtU'Uh]cb'k]''fYei]fY'hk c'dYcd'Y''

For the installation of Harlequin Vinyl Dance Floors, we recommend the use of Harlequin double sided high tack/low tack PVC tape, or a similar high quality plasticiser resistant PVC double-sided tape.

Should you choose not to use Harlequin double-sided tape, please check with the adhesive tape manufacturer to ensure that their double-sided tape is suitable for use with Harlequin Vinyl Dance Floors and PVC Welding Rods.

For all other Harlequin Floors, allow the floor to "relax" as described before. Lift back the floor at either side of the joint, being sure not to let the floor move.

Turn back one edge of each of the joints and mark the sub-floor with chalk to follow the approximate line of the joint. Lay a line of double-sided tape on each side of the chalk line, but do not remove the top release paper from the tape yet. Do not put double-sided tape on the ends of each length of flooring.

Starting at one wall, remove the release paper from the tape nearest to one wall and smooth the flooring down onto the tapežVfi g\]b['ci hUbmU]f'Vi VV'Yg'k]h' U'gcZ'h'Vfcca 'Ug'nci '[c.

Working away from this first line of tape, ease out any fullness in the flooring and smooth the opposite edge down onto the next line of tape, removing the release paper'UbX' Vfi g\]b['ci hUbmU]f'Vi VV'Yg'k]h' U'gcZ'h'Vfcca 'Ug'nci '[c''

Remove the release paper from the next line of tape and lay the second length of flooring onto it, so that the edges of the flooring almost touch, but leave a clean hairline gap.

Continue in this way until all lengths of flooring have been laid.

It may helpful with raw cement floors and some wood floors to prime the strip where the double-sided tape will be placed. This will make the tape stick better. To prime the floor, brush regular strength wallpaper adhesive (or a 10:1 dilution of PVA wood glue) and allow it to dry. This will make the floor a little shiny, or less "powdery", and the double-sided tape will get more grip.